



INSTRUCTION MANUAL

NERO WAVE HAIR DRYER

Product Number: 7411901


SPECIAL FEATURES:

1. Tourmaline technology seals the hair cuticles and reduces frizz and static, leaving hair shiny.
2. Long life motor and high quality switches.
3. Safety filter and overheating protection.
4. Professional slim air concentrator.
5. Hang-up hook.

HOW TO USE YOUR HAIRDRYER

1. Always ensure the switch is set to OFF position before plugging the unit into the power outlet.
2. Use the high setting for drying hair, and the low setting for styling.
3. If the hair dryer stops for any reason turn it off at once and let it cool down.
4. Switch control:

0 – OFF Position	1 - LOW: Medium warm temperature.
1 - LOW: Low speed	2 - MIDDLE: Medium hot temperature
2 - HIGH: High speed	3 - HIGH: Hot temperature



Cool shot: After drying hair, press the cool shot button to fix your style and add shine.

5. The hairdryer can be used with or without the concentrator.
6. Switch off after using, and remove plug from the socket.
7. The tourmaline technology automatically operates when the dryer is in use.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Never connect the dryer to incorrect voltage.
2. If the supply cord is damaged, it must be replaced by the manufacturer, service agent, or similarly qualified person in order to avoid hazard.
3. Make sure that the air outlet and grill are unobstructed.
4. The dryer is protected against overheating. It stops automatically when overheating and starts again after a short time of cooling. When the dryer stops automatically and you don't need to use it again, ensure you switch it off and remove the plug from the socket.
5. Do not put the air outlet too close to your hair. Please switch off the dryer for lengthy breaks in the drying process and disconnect it after use.
6. Keep the dryer out of reach of children.
7. Do not immerse the dryer in water or use in dampness.
8. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance



WARNING:

1. Do not use this appliance near water. Do not use the appliance with wet hands.
2. Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
3. When the hairdryer is used in the bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off.
4. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

MAINTENANCE



IMPORTANT: Always ensure that the hair dryer is disconnected from the main supply before cleaning. Use a damp cloth for cleaning and wipe dry. This will help preserve the original finish of your hair dryer. Abrasive cleansers should not be used.

WARNING: Never immerse the hair dryer in water and always ensure that plug is kept dry. After a period of use, you should take the inlet apart and clean it. Push the air inlet grill to the left to remove.

After cleaning, insert the air inlet grill onto the back of hair dryer and move to the right until locked in the right position.

Frequently clean out any hair or fluff that becomes stuck in the inlet filter to prevent overheating.

The list of the marking symbol

V	Volt	Hz	Hertz
W	Watt	~	Alternating current
	Class II appliance symbol		Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Images in this manual are for illustrative purposes only.

Due to constant improvements, we advise that changes to the design, material, specifications and product configuration may occur at any time without notice.

Backed by the Nero 1 Year Warranty

Imported By

R. Weatherdon & Co Pty Ltd

Sydney - Australia

www.weatherdon.com.au

Made in China